5/41

DART AEROSPACE LTD

Work Order: 24313

Description: Spacepod Hardware Kit

Part Number: K10018

Dwg:

Qty: 1 5 Kits

Ref: K10018

Step	Location	Procedure	Ву	Date	Qty
1	DC	Issue Traveler (1) K10018 requires (2) D2174-041. (1) D2174-041 consists of (1) D2174-1; (1) D2175-1; (1) D2175-2	H	05.09.21	5
2	KP	1 D2985 Decal 1839 569 16 AKS7-1032-130 Insert 18293	138	14314	
		0 ANGULAA D. H. (- ANGULA) - 11 (720) 71	r159	1 3 ×®	
	,	8 MS24694S67 Screw 0× M 1570C/M1713	70	00/11/02	1
3	QC4	Inspect Kit 100% for Completeness on the W/O	CL	05/11/02	
4	ST	Identify and Stock	10	05/11/02	1
5	AC	Cost / part: 81, 71	Suc	05-11-03	1
6	DC	Close W/O 70.5 V Inspect Level 21	13	05-11-03	1

Rev	Date	Change	Revised By	Approved
Α	03.03.26	New issue	KJ/RF	
В	04.06.09	Remove procedure for D2174-1/D2175	KJ/RF	1
C	04.08.30	Removed assembly of D2174-041	KJ/JLM (6111



